




## Anti-Arc Protection *ref: 041318*



### Information:

1. Connect the Anti-Arc Protection to the vehicle, (The LED will show green).
2. If a dangerous level of voltage is detected by the device it will be absorbed by the unit to prevent dangerous voltage entering the vehicle and damaging sensitive electronic components.



3. If the unit is 'activated' then the light shows red and the buzzer sounds. Once the unit has been activated it is rendered useless for future use and must be replaced.